


Scale-Link™

Wireless

The industry standard take-off tool for entering linear measurements from your blueprints, maps, or plans into any Windows program. Just roll the scaler wheel along your print, then click to instantly transfer the measurement into your program. Scale-Link Wireless contains everything you need to get started. The included PlanWheel can be used remotely in the field or interfaced with your PC at distances of up to 25 feet!




Select units of readout
(inches, feet, yards, meters, etc.)

Zero the count
and length

Click here to
transfer length from
PlanWheel WL into
software program

Transfer count from
PlanWheel WL into
software program



The Ready Connect™ window indicates readout from the PlanWheel WL™.

Change user defined
scales, adder, etc.

Select scale factors

- Architectural, Engineering, Map, and Metric
- 111 Built-in
- Thousands of available user-defined
- Create any custom scale with auto-scale feature



Scale-Link Wireless Includes:

- PlanWheel WL™ Scaler
- Ready Connect™ Software
- Charging Cradle w/ USB Cable
- Protective Case
- One Year Warranty
- User Manual
- Rechargeable Batteries (2AAA)

Scale-Link is specially suited for:

- All Windows construction estimating software
- Excel®, Quatro Pro®, Lotus 1-2-3® and other spreadsheets
- Access®, dBase®, Paradox®, Foxpro®, and other databases

System Requirements

- Windows® Compatible Computer
- CD-ROM Drive
- USB Port

Scale-Link works with all Windows® operating systems.